



15	0400015	1	Sight
18	0400018	1	Hand Spring
19	0000019	1	Trigger Bolt Spring (Sear)
20	0602020	1	Main Spring
21	0400021	1	Base Pin
22	0400022	1	Hand Spring Pin
26	0602026	1	Triggerguard (Steel)
30	0400030	2	Hammer Pin
31	0000031	1	Triggerguard Screw
32	0000032	1	Triggerguard & Backstrap Screw
35	0400035	3	Bolt Spring Screw
36	0000036	2	Main Spring screw
37	0400037	4	Hammer Screw
38	0400038	1	Trigger Screw
40	0400040	1	Bolt Screw
43	0602043	1	Right Grip Nut
44	0602044	1	Left Grip Nut
45	0602045	1	Right Grip Assembly
46	0602046	1	Left Grip Assembly
51	0602051	1	Grip Pin
54	0602054	1	Grip Screw
91	0150091	1	Hammer Safety Bar
98	0400098	1	Firing Pin
134	0400134	1	Gate Catch
135	0300135	1	Ejector Spring
136	0300136	1	Gate Spring
137	0300137	1	Base Pin Spring
139	0400139	1	Base Pin Nut
140	0400140	1	Base Pin Screw
142	0400142	1	Gate
143	0400143	1	Ejector Rod Tube
144	0400144	1	Ejector Rod Tube Screw
145	0400145	1	Gate Catch Screw
147	0602147	1	Hammer Safety Spring
150	0400150	1	Hammer Safety Plunger

151	0150151	1	Hammer Safety Plunger pin
164	0400164	1	Ejector Nut .357 Mag Assembly
187	0400187	1	Base Pin Bushing
692	0400692	1	Hand Pin Screw
<b>ALTERNATIVES</b>			
3	0401003	1	Barrel 5 1/2" .357 Mag Assembly
3	0405003	1	Barrel 7 1/2" .357 Mag Assembly
3	0414003	1	Barrel 4" .45 LC-45ACP Assembly
3	0410003	1	Barrel 4 3/4" .45LC-.45ACP Assembly
3	0411003	1	Barrel 5 1/2" .45LC-.45ACP Assembly
3	0415003	1	Barrel 7 1/2" .45LC-.45ACP Assembly
3	0420003	1	Barrel 4 3/4" .44/40 Assembly
3	0421003	1	Barrel 5 1/2" .44/40 Assembly
3	0425003	1	Barrel 7 1/2" .44/40 Assembly
3	0680003	1	Barrel 4 3/4" .44Sp. Assembly
3	0685003	1	Barrel 4 3/4" .38/40 Assembly
3	0686003	1	Barrel 5 1/2" .38/40 Assembly
3	0687003	1	Barrel 7 1/2" .38/40 Assembly
5	0410005	1	Cylinder .45LC Assembly
5	0402005	1	Cylinder .45ACP Assembly
5	0420005	1	Cylinder .44/40 Assembly
5	0680005	1	Cylinder .44Sp.
5	0685005	1	Cylinder .38/40 Assembly
164	0410164	1	Ejector Nut .45-44/40 Assembly